


TYPE 1,2

⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530071927	Kit-Trigger/Lockout	24.	530059677	Starter Hub-EPS	44.	545012003	Cover-Clutch
2.	545011903	Cover-Handle	25.	530021180	Spring-EPS	45.	952051338	Accy-18" Chain
3.	530016433	Screw	26.	530071966	Kit- EPS Starter Pulley (Incl. 23,24,25,32)	46.	952044926	Accy-18" Bar
4.	530023877	Fitting-Fuel line	27.	545011703	Housing-Fan	47.	530016432	Screw
5.	530069216	Kit-Fuel Line (Large)	28.	530056402	Handle-Starter	48.	530016443	Screw
6.	530069247	Kit-Fuel Line (Small)	29.	530069232	Kit-Rope	49.	530059480	Assy-Rear Iso. Spring
7.	530095646	Assy-Fuel Pick Up	30.	530016432	Screw	50.	530015906	Screw
8.	545012103	Handle-Rear	31.	530042095	Spring-Starter	51.	530059479	Assy-Front Iso. Spring
9.	530059475	Spring-Rear Isolator	32.	530016080	Screw	52.	530057878	Handle-Front
10.	530071945	Kit-Clutch Washer	33.	530057868	Baffle	53.	530016432	Screw
11.	530057905	Assy-Clutch Drum 3/8"	34.	530058786	Assy-Oil Vent	54.	530071945	Kit-Clutch Washer (Incl. 10,12)
12.	530071945	Kit-Clutch Washer	35.	530057236	Assy-Oil Cap w/ret.	55.	530057924	Assy-Oil Pick Up
13.	530057907	Assy-Clutch	36.	530057880	Handguard	56.	530071891	Kit-Oil Pump (Incl. 57,58,59)
14.	530016419	Washer-Large Clutch	37.	530016416	Spring-Handguard	57.	530016064	Screw
15.	530015906	Screw	38.	545011803	Assy-Chassis (Incl. 4,5,6,7,9,15,16,17,18, 20,34,35,37,41,51)	58.	530057931	Assy-Oil Pump
16.	530047192	Assy-Fuel Cap w/ret	39.	530071893	Kit-Chainbrake	59.	530037820	Gear-Worm
17.	530016064	Screw	40.	530016432	Screw			
18.	530015922	Nut-"U" type speed	41.	530016133	Bolt-Bar			
19.	530039231	Assy-Flywheel	42.	530057910	Plate-Bar			
20.	530057911	Shield-Heat	43.	530015917	Nut-Bar			
21.	530015127	Washer-Flywheel						
22.	530016134	Nut-Flywheel						
23.	530021179	Screw-Shoulder						


✓ = NEW PART NUMBER FOR THIS IPL

* = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

TYPE 2



⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016153	Screw	19.	530071889	Kit-Carb. Adaptor (Incl. # 20,38,41)	36.	530038729	Ring-Piston
2.	530039232	Module-Ignition	20.	530071894	Gasket-cyl. o-ring (kit)	37.	530057886	Insert-Right (gray)Cyl.
3.	530016432	Screw	21.	952030150	Accy-Spark Plug (RCJ-7Y)	38.	530071894	Seal-Adaptor (kit)
4.	530058661	Strap-Ground	22.	530071884	Kit-Cylinder (Incl. 29,37)	39.	530016426	Screw
5.	530057943	Assy-Wire Harness	23.	530058660	Clip-High Tension Lead	40.	530071894	Gasket-Carb. (kit)
6.	530055698	Reflector-Tape	24.	545006007	Kit-Muffler (Incl. 25,26,27,28)	41.	530057926	Tube-Intake
7.	530057872	Shield-Cylinder(Incl. 1,6)	25.	530057942	Backplate-Muffler	42.	530016101	Nut-Carb.
8.	530016080	Screw	26.	530071894	Gasket-Muffler (kit)	43.	530071894	Kit-Gasket (Incl. 20,26,38,40)
9.	530057891	Lever-Ignition Switch	27.	545006056	Kit-Spark Arrestor	44.	530031135	Scrench
10.	530057908	Spring-Ignition Switch	28.	530016338	Bolt-Muffler			Not Shown
11.	530059399	Knob-Choke	29.	530057885	Insert-Left (black) Cyl.	✓	545137234	Manual-Operator
12.	530059001	Cover-Air Filter	30.	530012537	Assy-Crankshaft/Rod		530059905	Decal-Warning
13.	530057869	Filter-Air	31.	530016417	Bolt			
14.	530016425	Screw	32.	530057941	Cap-Crankcase			
15.	530150029	Housing-Air Filter w/cable	33.	530056363	Assy-Bearing/Seal			
16.	---	Carburetor	34.	530071883	Kit-Piston (Incl. 35,36)			
17.	530069247	Kit-Fuel Line (Small)	35.	530015697	Retainer-Piston Pin			
18.	530047721	Bulb-Purge "snap-in"						

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)