



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015957	Screw	26.	530010845	Assy-Fuel Cap	50.	530016080	Screw
2.	530071272	Cover-Handle (kit)	27.	530037551	Assy-Chassis (Incl. 22,23,24,26,43,47 Fuel line and filter)	51.	530042095	Spring-Recoil
3.	530036097	Trigger-Throttle	28.	530069572	Kit-Switch	52.	545008803	Housing-Fan
4.	530036098	Lockout-Throttle	29.	530029833	Worm-Oil Pump	53.	530015892	Screw
5.	530053443	Lever-Choke	30.	530014410	Assy.-Oil Pump	54.	530015814	Screw
6.	530015937	Screw	31.	530015896	Screw	55.	530015158	Washer
7.	530038985	Spring-Isolator	32.	530069342	Kit-Clutch Drum (Incl. #35)	56.	530038327	Handle-Front
8.	530071272	Handle-Rear (kit)	33.	530015611	Washer-Clutch	57.	530036113	Front Strap-AV
9.	530015906	Screw	34.	530014949	Assy-Clutch	58.	530015775	Screw-Plate
10.	530038986	Spring-Isolator	35.	530032119	Bearing-Clutch	59.	530036101	Plate-Isolator
11.	530038471	Assy-Throttle Cable (Incl. Grommet)	36.	530015907	Washer-Thrust	60.	530038985	Spring-Isolator
12.	530069232	Kit-Rope	37.	530019174	Seal-Oil	61.	530015984	Screw
13.	530049797	Handle-Starter	38.	545047801	Pickup-Oil	62. ✓	952051310	Chain"- 20"
14.	530071966	Kit-Starter EPS (Incl. 15,16,17,50)	39.	530056533	Filter-Oil	63. ✓	952044815	Bar -20" Quick Adjust
15.	530021180	Spring EPS	40.	530016037	Screw	64.	530054804	Assy-Chain Brake
16.	530059677	Hub-Starter EPS	41.	530015814	Screw	65.	530015917	Nut-Bar Mounting
17.	530021179	Screw-Shoulder	42.	530029850	Chain Catcher			
18.	530047667	Plate-Baffle Fan	43.	530015877	Bar Bolt			
19.	530016134	Nut-Flywheel	44.	530047855	Bar Plate			
20.	530015127	Washer-Flywheel	45.	530016439	Screw			
21.	530059637	Assy-Flywheel	46.	530014381	Kit-Spike Assy (incl #45)			
22.	530036043	Plate-Support (Bar Stud)	47.	530057236	Assy-Oil Cap			
23.	530029868	Plug-Vent	48.	530055406	Shield-Heat			
24.	530026119	Valve-Check	49.	530055322	Clip-"U"			
25.	530015922	Nut-Speed						

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)