


# ROTARY LAWN MOWER -- MODEL NUMBER P4TN20SA (386990)



## ROTARY LAWN MOWER - - MODEL NUMBER P4TN20SA (386990)

3

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	131696	Control Bar	34	62335	Belleville Washer
2	186079	Rope Guide / Anti-Fold Bracket	35	142748	Shoulder Bolt
3	851201X004	Engine Washer	36	800060	Wheel and Tire Assembly
4	183496X479	Upper Handle	37	83923	Nut, Hex
5	151590X479	Lower Handle	41	149741	Thread Cutting Screw 5/16-18 x 3/4
7	131959	Handle Bolt 5/16-18 x 1-3/4	42	85463	Danger Decal
8	850733X004	Up-Stop Bracket	43	751592	Locknut 3/8-16
9	189241	Hex Washer Head Screw #10-24 x 1/2	44	150406	Hex Head Thread Rolling Screw 3/8-16 x 1-1/8
10	164322	Engine Zone Control Cable	46	189431	Kit, Lawn Mower Housing
12	66426	Wire Tie	49	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
13	51793	Hairpin Cotter	50	850263	Helical Lock washer 3/8
14	136376	Knob	51	851074	Hardened Washer
15	752052	Discharge Guard	52	145106	Blade, 20"
17	73800400	Locknut 1/4-20	53	850977	Blade Adapter
19	851855	Torsion Spring	56	---	Engine, Tecumseh, Model Number LV148EA (For engine service and replacement parts, call Tecumseh at 1-800-558-5402)
21	88602	Hinge Deflector			
22	150215	Hinge Rod			
23	189240	Rear Deflector	57	132004	Nut, Hex
24	750085X007	Wheel Adjusting Bracket	58	750634	Screw
26	170345X479	Handle Bracket Assembly, Right	--	161058	Warning Decal (Not Shown)
27	170346X479	Handle Bracket Assembly, Left	--	172782	Operator's Manual, English
28	61537	Washer	--	172784	Operator's Manual, Spanish
29	146630	Spacer	--	189430	Replacement Parts Manual, English
31	700331X004	Selector Spring			
32	87877	Selector Knob			
33	145935X479	Axle Arm Assembly			

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm