


ROTARY LAWN MOWER - - MODEL NUMBER PO45N21R (PO45N21RA)



ROTARY LAWN MOWER - - MODEL NUMBER PO45N21R (PO45N21RA)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	86902	Control Bar	37	700263	Wheel Assembly
2	169709X479	Upper Handle	39	83923	Flanged Locknut
3	169708X479	Lower Handle	40	188813	Frame, Grass Bag
4	179585	Rope Guide / Anti-Fold Bracket	41	88652	Hinge Screw
6	191574	Handle Bolt	42	165766	Spring, LH
7	66426	Wire Tie	43	165767	Spring, RH
11	176556	Engine Zone Control Cable	44	184193	Door Bolt
12	750634	Hex Washer Head Screw	45	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
13	86899X004	Up-Stop Bracket	46	141846	Danger Decal
14	128638	Handle Knob	48	186575X004	Axle Arm Assembly, RR
15	51793	Hairpin Cotter	49	132004	Nut, Hex
17	165946X479	Support Bracket	50	188965	Grass Bag
18	17600406	Screw	52	191560	Kit, Housing (Includes Key Numbers 17, 18 and 46)
19	186577X004	Axle Arm Assembly, LF	53	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
20	186578X004	Axle Arm Assembly, RF	54	850263	Helical Lockwasher
21	188987	Rear Skirt	55	851074	Hardened Washer
22	168360X004	Selector Spring, Front	56	189028	21" Blade
23	186612	Rear Door Kit (Includes Springs)	57	850977	Blade Adapter
24	73930500	Locknut, Hex 5/16-18	59	---	Engine, Briggs & Stratton, Model Number 10M902 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
25	166111X479	Handle Bracket Assembly, LH	--	161058	Warning Decal (not shown)
26	166112X479	Handle Bracket Assembly, RH	--	172782	Operator's Manual, English
27	851856	Screw 1/4-20 x 3/8	--	172784	Operator's Manual, Spanish
29	160835X007	Wheel Adjusting Bracket, Front	--	191559	Repair Parts Manual, English
30	183901	Washer			
32	169421X004	Selector Spring, Rear			
33	87877	Selector Knob			
34	186576X004	Axle Arm Assembly, LR			
36	160828	Shoulder Bolt 5/16-18			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm